

# Instruction for

# GB Net Swing

Art.-No. 4915



**Please read these instructions carefully and thoroughly before using.**


**Usage:** Swing when it is suspended from the fixed points.

## Assembly Instruction:

1. Take the swing out of the box and inspect the contents. In the event that the material is not up to an acceptable standard, please stop using immediately and report any faults to your supplier.
2. Fix the swing on two strains of a tree or other strong fixing points / frames.
3. Take off your shoes before using the swing. Keep the swing steady and carefully sit down on the swing. Then put one leg after the other on the swing.
4. For safety reasons, it is recommended to use your swing above a soft surface such as a green ground. If on hard surfaces place a mat under the swing to prevent any dangerous falls.
5. Keep these instructions for future reference.
6. STOP using if any parts of the swing broken or loosen.

## Using Safety Instruction:

1. Read the instructions carefully before use.
2. Before starting to use the swing, make sure the rings are strongly attached, so that a release or slipping of the rope can be ruled out.
3. The height of the attachment points of the swing should only be high enough to enable you to sit comfortably. The corresponding height is **40 cm** above the floor, exceeding this level is forbidden.
4. Maximum capacity is **100 kg**.
5. The swing is not permitted to be used as a hammock - maximum tilt of **45 °**.
6. Do not place anything under the swing.
7. Do not jump on the swing or off the swing.
8. The swing should be set only by adults, children under **12 years** old should only use this swing under adult supervision.
9. Place soft padding under the swing if the ground is hard.
10. Check the swing, the facilities, the fixing ring and hanging points carefully.
11. A secure fit is required before using.



## Maintenance Instruction:

1. Swing hooks and suspension must be greased regularly. Also check swing hooks and rings for rust points, which could affect their strength. It is recommended to replace any parts if the sturdiness is in any doubt.
2. Check the swing seats and trapezes for cracks or breaks
3. Check swing ropes for fraying or extreme wear resulting from the twisting of the swing accessories. In order to assess this you need to unwind the ropes at the point of suspected wear in order to check the swing rope fibres carefully for breaks. Replace if in any doubt.
4. The swing can be packaged in a bag (plastic or other material) after use, and make sure the swing is dry. Do not store it in direct sunlight.