


Assembly Instructions

Swing



Art. No. 6121

IMPORTANT - READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTURE REFERENCE



WARNING! CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS.
WARNING! MAXIMUM WEIGHT SHOULD NOT EXCEED 100KGS.
WARNING! DO NOT USE WITHOUT ADULT SUPERVISION!
WARNING! ADULT ASSEMBLING REQUIRED !

ESSENTIAL INFORMATION

- Recommended for children 3+ years
- Do not leave child unattended while in use
- CAUTION: Use only under adult supervision
- Good safety practices should be followed at all times
- Read all instructions before using this product.

Intended solely for family and domestic use, not for a commercial playground or daycare.

Two adults needed for assembly. Maximum weight capacity: 100KGS.

Hanging hardware not included. Ideally, the swing body should be hung over grass, sand, wood chips, or other soft surfaces. Under no circumstances should it be hung over concrete, asphalt, or other hard surfaces. Distance from ground should not exceed 40cm; the maximum fall height should not be more than 46cm. Two S hooks are attached to the rope to allow for adjustment of the rope length.

Please be sure to examine the ropes regularly to check for wear. Rope will, in time, degrade.




If the colour of the rope has become pale, frays easily, or gives off a powdery material when rubbed between the fingers, we recommend you replace the rope.

Equipment should be hung in such a way that a distance of at least 2m is clear on either side.

Can be hung on an A-frame or swing set or on a tree limb of a diameter of at least 25cm.



WARNING! Small parts for assembly by an adult.




Legler OHG small foot company
Achimer Straße 7
27755 Delmenhorst / **Germany**
www.smallfoot-legler.com

Find us on 
facebook.com/smallfootlegler

 **Attention! Assembly by an Adult!**

Assembly Instructions

Swing



Ensuring Safety of the swing

Clearance distance should be 2m around the swing.

A fall onto a hard surface can result in serious injury to the equipment user.

Do not use the equipment until properly installed.

This swing is not to be used in any other manner than its intended use.

Adult supervision is required.

Adults should verify that the hanging ropes are secured and cannot be looped back on the swing.

It is important for adults to instruct children to:

- Dress appropriately while using the swing (avoid ponchos, scarves, and other loose-fitting clothing that is potentially hazardous)
- Sit in the center of the swing with full weight on the seat if swinging alone
- Avoid swinging empty seats

It is important for adults to instruct children **NOT to**

- Walk close to, in front of, behind, or between moving items
- Twist ropes or loop them over the top support bar since such action may reduce the strength of the rope
- Get off the sing while it is in motion
- Climb on the swing when it is wet.
- Attach additional items to the swing that might cause a strangulation hazard.
- Wear a bicycle or sport helmet while on the swing.

Maintaining the swing

At the beginning of the each play season, adults should:

- Tighten all hardware.
- Check all protective coverings on pipes, edges, and corners, Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seat, ropes for wear, rust, or other deterioration, Replace as needed. The hardware used for this swing (binding post, screw, S hook, lock washer, flat washer, and metal ring) can be found at local hardware store.
- Check metal parts for rust, if found, and repaint using a non-lead-based paint meeting the EN71 requirements.
- If the swing is hung from swing set frame, then lubricate all metallic moving parts, that are attached by a metal connection.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials (such as mulch or sand) to prevent compaction and to maintain appropriate depth(Min amount is 25cm), replace as needed.

Twice a month during play season, adults should:

- Tighten all hardware
- Check all protective covering on pipes, edges and corners, Replace if they are loose, cracked, or missing.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials(such as mulch or sand) to prevent compaction and to maintain appropriate depth(Min amount 25cm) Replace as needed.

Once a month during play season, adults should:

- Check all moving parts including ropes for wear or other deterioration. Replace as needed.
- If the swing is hung from a tree branch, then rake and check depth of loose-fill protective surfacing materials (such as mulch or sand) to prevent compaction and to maintain appropriate depth(Min amount 25cm) Replace as needed.

At the end of each play season, or when the temperature fall below 4°C adults should:

- Remove the swing from its outdoor location.
- Store the swing in a dry environment.

Disposing of the swing

To dispose of the swing, first disassemble it, Dispose of it in such a way that no unreasonable hazards will exist at the time that the swing is discarded.

This confirms to EN71, Consumer safety performance specification for home playground equipment.

Find us on 
facebook.com/smallfootlegler



Legler OHG small foot company
Achimer Straße 7
27755 Delmenhorst / **Germany**
www.smallfoot-legler.com